```
In [1]:
          import rasterio
          from rasterio import plot
          import matplotlib.pyplot as plt
          import numpy as np
          %matplotlib inline
In [2]:
          band4=rasterio.open("B5_swir1.tif")
          band5=rasterio.open("B7_swir2.tif")
In [3]:
          fig, (ax1, ax2) = plt.subplots(1, 2, figsize=(12, 6))
plot.show(band4, ax=ax1, cmap='gray', title='SWIR1')
plot.show(band5, ax=ax2, cmap='gray', title='SWIR2')
          fig.tight_layout()
                                   SWIR1
                                                                                                SWIR2
          4.541
          4.540
          4.539 -
                                                                       4.539
          4.538
                                                                       4.538
          4.537
                                                                       4.537
          4.536
                                                                       4.536
          4.535
                         697000
                                          699000
                                                                                      697000
                                                                                               698000
                                                                                                       699000
In [4]:
          swir1=band4.read(1).astype('float64')
          swir2=band5.read(1).astype('float64')
In [5]:
          NDSI=np.where(
               (swir1+swir2)==0.,
               (swir1-swir2)/(swir1+swir2))
          NDSI_image = rasterio.open('NDSI_image.tiff','w',driver='Gtiff',
                                        width=band4.width,
                                        height = band4.height,
                                        count=1, crs=band4.crs,
                                        transform=band4.transform,
                                        dtype='float64')
          NDSI_image.write(NDSI,1)
          NDSI_image.close()
In [7]:
          NDSIimg = rasterio.open('NDSI_image.tiff')
          fig = plt.figure(figsize=(18,12))
          plot.show(NDSIimg, cmap='gray', title='Normalized Difference Salinity Index')
                                    Normalized Difference Salinity Index
```

